


SHRUB PLANTNIG DETAIL TREE PLANTING DETAIL



SHUB PLANTING DETAILS

NOTES: SMALL TREE PLANTING (<2" CAL.)

NOTES: TYPICAL SHURB PLANTING, INDIVIDUAL PLANTING HOLE 1. DIG PLANTING HOLE AT LEAST 2X THE WIDTH OF THE ROOT BALL OR CONTAINER.
2. SCARIFY SUBGRADE AND SIDES OF PLANTING HOLE WHEN PLANTING IN CLAY SOIL.
3. SET THE TOP OF THE ROOT BALL LEVEL WITH THE SOIL SURFACE, OR 1-2" ABOVE IF THE SOIL IS PRONE TO SETTLING.
4. IF CONTAINER GROWN PLANT, GENTLY SLIDE PLANT OUT OF CONTAINER. DISTURB THE ROOTS.
5. IF B&B PLANT, REMOVE BURLAP FROM AT LEAST THE TOP 12 INCHES OF THE ROOTBALL, WITHOUT DISTURBING THE ROOTBALL, REMOVE ALL CORD FROM THE TRUNK. REMOVE BURLAP AND WIRE BASKET (IF PRESENT) FROM THE ROOT BALL. BASKET (IF PRESENT) FROM THE ROOT BALL.

6. BACK FILL THE PLANTING HOLE WITH
EXCAVATED NATIVE SOIL, BROKEN UP OR TILLED.
WATER TO REMOVE AIR POCKETS, DO NOT ADD
AMENIDABLYS

AMENDMENTS. 7. PLACE PINE STRAW OR BARK MULCH ON THE SURFACE TO A (SETTLED) DEPTH OF 1 TO 3 TREE PLANTING DETAIL

1. ALL PLANT MATERIALS SHALL BE IN ACCORDANCE WITH THE AMERICAN STANDARDS FOR NURSERY STOCK (ANSI 260.1-2004). PLANT ACCORDING TO ANSI A300 PART 6.

2. DIG THE PLANTING HOLE A MINIMUM OF 2x WIDTH OF ROOTBALL FOR AT LEAST THE FIRST 12 INCHES OF DEPTH. BELOW 12 INCHES, DIG HOLE WIDE ENOUGH TO PERMIT ADJUSTING. DO NOT DIG THE HOLE DEEPER THAN ROOT BALL DEPTH.

3. SCARIEY THE SUBGRADE AND SIDES OF THE PLANTING HOLE WHEN PLANTING IN CLAY SOILS (MORE THAN 15% CLAY).

4. LIFT AND SET THE TREE BY ROOT BALL ONLY. DO NOT LIFT USING THE TREE TRUNK AND DO NOT USE TREE TRUNK AS A LEVER.

5. SET THE TOP OF THE ROOT BALL LEVEL WITH THE SOIL SURFACE OR SLIGHTLY HIGHER IF THE SOIL IS PRONE TO SETTLING.

6. AFTER THE TREE IS SET IN PLACE, REMOVE BURLAP, WIRE AND STRAPS FROM AT LEAST THE UPPER 1/3 OF THE ROOTBALL.

7. BACKFILL WITH EXISTING SOIL THAT HAS BEEN WELL-TILLED OR BROKEN UP. DO NOT ADD AMENDMENTS TO THE BACKFILL SOIL. AMEND THE SURFACE WITH MULCH.

8. USE TWO 2" X 2" WOOD STAKES 1/3 TREE HEIGHT IN LENGTH DRIVEN INTO UNDISTURBED SOIL A MINIMUM OF 16 INCHES. STAKES SHOULD BE SPACED EQUALLY ACROSS FROM AND IN LINE WITH THE TRUNK PARALLEL TO THE PREVAILING WIND.

9. ATTACH 3/4" NYLON WEBBINS TO CONNECT THE TREE TO STAKES. ATTACH WEBBING AT 1/3 THE TREE HEIGHT.

10. APPLY A 2-3" (SETTLED) DEPTH OF PINE STRAW OR BARK MULCH TO THE PLANTING SURFACE. LEAVE A 2" SPACE AROUND THE TRUNK FOR AIR CIRCULATION.


11. PRUNING SHALL BE LIMITED TO DEAD, DISEASED, OR BROKEN LIMBS ONLY AND SHALL BE IN ACCORDANCE WITH AND SAGO SPECIFICATIONS.





Majestic Builders Inc

LICENSE# 581822 (916) 257-5224 11241 Coloma Rd. Suite D Gold River, ca 95670



APN: 050-010-017-000 PAGE 6 OF 9

I have reviewed and I give my approval to proceed with the construction of this project.

Customer Signature Date approximate and do not take the place of an engineer's survey.

NB Designs in partnership with Majestic Builders is not responsible for any modifications or adjustments of the Design concept that may be necessary by the homeowner or contractor to




























Majestic Builders Inc

LICENSE# 581822 (916) 257-5224 11241 Coloma Rd. Suite D Gold River, ca 95670



PHASE 1 - PROJECT RENDERINGS
APN: 050-010-017-000
PAGE 7 OF 9

I have reviewed and I give my approval to proceed with the construction of this project.

X
Customer Signature Date

Landscape Design concept is diagrammatic. Actual site conditions take precedence over Design concept. Measurements are approximate and do not take the place of an engineer's survey.

NB Designs in partnership with Majestic Builders is not responsible for any modifications or adjustments of the Design concept that may be necessary by the homeowner or contractor to execute this design.

NOTES REVISIONS